



# VICE<sup>®</sup>

VIBRATING PROSTATE MASSAGER



USER GUIDE

# INDULGE YOUR VICE FOR PLEASURE WITH OUR PATENTED VIBRATING MASSAGER!



To operate vibrator, insert battery as illustrated above and hold button firmly until unit begins to vibrate.

## ADDITIONAL BULLET INSTRUCTIONS

1. Turn the vibrating bullet on and off by pressing and holding down the on/off button.
2. Press the button quickly to cycle through the different vibration patterns.
3. Double-clicking the button will allow you to cycle backwards through the vibration patterns

## PREPARATION

1. Wash the Vice® with warm soapy water before and after use. Always wash the bullet vibrator with its end cap securely fastened and never submerge in liquid.
2. Apply a liberal amount of lubricant to yourself and to the Vice before insertion.

## INSTRUCTIONS

1. The Vice may be used with or without the bullet vibrator. For vibration during use, insert the vibrator into the cavity of the massager.
2. Slowly insert the Vice, positioning the perineum tab to press against the area between the anus and the scrotum (the perineum).
3. Turn Vice on by pressing and holding down the button. Cycle through the different vibration patterns by pressing the button quickly.

## TIPS

1. Make sure the rectum is empty before use, rinsing with a rectal syringe is recommended.
2. Use only glycerin-free, water-based lubricants.
3. Wash the Vice before and after every use.
4. Never submerge the device with the vibrating bullet inserted.
5. Enjoy yourself and experiment with different positions, breathing exercises, relaxation techniques, and methods of arousal.

**Warning:** Silicone-based lubricant will cause the massager to deteriorate. Do not use this product if you have Nickel allergies – the vibrating bullet is crafted from high grade stainless steel and contains Nickel. If you experience any pain or discomfort during use, you should discontinue use of the product.